

COPIER OPERATIONS TIP OF THE MONTH
March 2015

WASTE STAPLE CONTAINER

Partners, when your machine gives you an error code of SC 737, that means the waste staple container needs to be emptied. The waste staple container is located in the back on the bottom of the finisher. The container can be removed by first removing the locking pin, then pulling the container straight back.

After you put the container back into position, reboot the machine from the main power switch to reset the error code.

Pete Patellis
Customer Service Specialist
TeamWorks Central
Montgomery County Public Schools
301-279-3110